




AMR 80 Thermal receipt printer -USB interface installation instructions.


- 1) From the AMR 80 installation CD, open folder labeled [USB VCP Driver](#).




- 2) Run file [CDM_Setup.exe](#).




- 3) Connect printer USB cable and power on printer. Windows will find new USB device.
- 4) After running Step 2 look under Device Manager – Ports(COM & LPT), a USB Serial Port(COM X) will be listed.




- 5) Go to Windows [Control Panel](#) and open [Printers and Faxes](#)
- 6) Select [Add a printer](#) and run wizard, uncheck [Automatic printer detection](#)




7) From the drop down window select **COM (serial port)** listed in Step 4.




8) Select "Have Disk" and browse the AMR 80 CD for the **AMR80v26.inf** file located under the **WDM Drive folder**, highlight and click open.



9) Select Next >



10) Name printer or leave default and click Next >.



11) Click NO for printing a test page.

12) Finish installation



13) AMR 80 printer will now be listed under Printers and Faxes.

