

TEK8600 Titan Quick Start Guide

The TekVisions TEK8600 requires no additional drivers or software.


The TEK8600 Orbital Scanner is ready to use as a Titan Left or Right Scanner.

Each Scanner is marked as:

Titan Left or Titan Right


The Titan software mode must be set to buffered to work with The Titan Left and Right TEK8600 Orbital Scanner.

To enable buffering, you must press the "Mode" key in the main POS screen.



Then select "Buffered".

Serving Mode ✕



For additional questions or support please contact our technical support department:

Fred Meyerhofer
support@tekvisions.com - 800.827.0127